

Spreader settings and application rates

Landscaper Pro

15-9-12+3MgO (Flora) | 27-5-5+2MgO (Full Season)

Applicable for the following ICL spreaders: **AccuPro 2000, SR-2000**

	Cone setting	Spread width	Rate and Setting					
			25 g/m ²	30 g/m ²	35 g/m ²	40 g/m ²	45 g/m ²	50 g/m ²
Single Pass	4	4,7 m	Q	R½	T½	V	X	Q(x2)
Double Pass (half rate)	4	4,7 m	M	N	O	O½	P	Q

Applicable for the following ICL spreaders: **AccuPro One**

	Slider plate	Spread width	Rate and Setting					
			20 g/m ²	25 g/m ²	30 g/m ²	35 g/m ²	40 g/m ²	45 g/m ²
Single Pass	Closed	2,5 m			14	16	18	
Double Pass (half rate)	Closed	2,5 m			9	10	11	

The spreader settings are guidelines only. The spreader should be calibrated prior to application to ensure accuracy. The spreader settings are based on a walking speed of 5 km/hour. Walking faster or slower than 5 km/hour will alter the spread width and application rate. Exact rates are dependent upon the spreader itself and the accuracy of the person operating it.